

UNDERBODY WATER TANK MOUNTING INSTRUCTIONS

1. Remove the mudguard support bracket.
2. Temporarily assemble the mounting brackets on the tank **(DO NOT OVERTIGHTEN)** and position the tank under the tray of the vehicle. Mark the position of the holes. Some bodies may require you to fit a dummy cross member to mount the rear brackets.
3. Fit the brackets to the body using either bolts or Tek screws. Remove the brackets.
4. Fit the brackets to the tank and mount up underbody. **(DO NOT OVERTIGHTEN, DO NOT USE RATTLE GUNS OR POWER TOOLS TO TIGHTEN BOLTS)**
5. Bend the mudguard bracket to fit the mounting location under the tank. Cut to length and drill to suit the hole position.
6. Flush out the tank then fill for use.

NOTE: ON final assembly it is advisable to use Loctite or similar on mounting bracket screws. Screws are 6-mm coarse metric stainless steel.

